HOOKAH & OCTO *EXPLODED VIEW*



Service Kit
Octo Second Stage

Part # RK9
Dealer 9.00

Includes:

1	3	13	14	16	18	20
21	23	26	28	29	31	33

Service Kit
Hookah Second Stage

Part # RK10
Dealer 9.00

Includes:

1	3	13	14	16	18
20	21	23	26	28	29

#	Part #	Description	Dealer
1	RP250-11	Tie Strap	0.50
2	RP310-02	Mouthpiece	3.50
3	RP310-03	Exhaust Valve	2.50
4	RP310-04	Exhaust Tee	6.00
5	RP310-05	Diaphragm	5.00
6	RP310-06	Thrust Washer	1.00
7A	RP310-07A	Front Cover - Black	5.00
7B	RP310-07B	Front Cover - Neon Yellow	5.00
7C	RP310-07C	Front Cover - Mellow Yellow	5.00
8	RP310-08	Purge Spring	1.00
9	RP310-09	Purge Button	1.00
10	RP310-10A	Purge Sticker - Hookah 50-80 psi	2.00
10	RP310-10B	Purge Sticker - Hookah 80-110 psi	2.00
10	RP310-10C	Purge Sticker - Hookah 110-140 psi	2.00
10	RP310-10D	Purge Sticker - Octo	2.00
10	RP310-10E	Purge Sticker - Octo Circular Logo	2.00
11	RP310-11A	Spring - Hookah 50-80 psi Hookah 80-110 psi	2.50
11	RP310-11D	Spring - Hookah 110-140 psi Standard Octopus	2.50
12	RP310-12	Poppet	4.00
13	RP310-13	Low Pressure Seat	1.00
14	RP310-14	O-ring	0.50
15	RP310-15	Inlet Fitting	4.00
16	RP310-16	O-ring	0.50
17	RP310-17	Adjustable Orifice	4.00
18	RP310-18	Lock Nut	1.00
19	RP310-19	Spacer	1.00
20	RP310-20	Lever	3.00
21	RP310-21	Washer	1.00
22	RP310-22	Lever Support	8.00
23	RP310-23	O-ring	0.50
24	RP310-24	Deflector	2.00
25	RP310-25	Locking Key	2.00
26	RP310-26	O-ring	0.50
27	RP310-27	Plug	2.00
28	RP310-28	C-clip	1.00
29	RP310-29	O-ring	0.50
30	RP310-30	Switch	2.00
31	RP200-29	O-ring	0.50
32	LP36	LP Hose - 36" Black	14.50
33	RP200-19	O-ring	0.50